

Teton Outsole Kwf Profi



Assemblage Guide



1. Place the head of the stud in the headquarters of the key provided.

2. Place the propeller of the stud on the surface of the sole of the shoes

3. Put force pushing in a longitudinal way with the included manual tool

4. Then tighten only until the head of the stud reaches the surface of the sole.



GRIP



TRACTION



BRAKING



STABILITY



CUSHIONING



SELF-CLEANING